



Determination of overpotential characteristics of reversible solid oxide cells via impedance spectroscopy and correlation with cell degradation

Graves, Christopher R.; Ebbesen, Sune Dalgaard; Hjelm, Johan

Publication date:
2011

[Link back to DTU Orbit](#)

Citation (APA):

Graves, C. R. (Author), Ebbesen, S. D. (Author), & Hjelm, J. (Author). (2011). Determination of overpotential characteristics of reversible solid oxide cells via impedance spectroscopy and correlation with cell degradation. Sound/Visual production (digital)

General rights

Copyright and moral rights for the publications made accessible in the public portal are retained by the authors and/or other copyright owners and it is a condition of accessing publications that users recognise and abide by the legal requirements associated with these rights.

- Users may download and print one copy of any publication from the public portal for the purpose of private study or research.
- You may not further distribute the material or use it for any profit-making activity or commercial gain
- You may freely distribute the URL identifying the publication in the public portal

If you believe that this document breaches copyright please contact us providing details, and we will remove access to the work immediately and investigate your claim.

Determination of overpotential characteristics of reversible solid oxide cells via impedance spectroscopy

Christopher Graves

Sune D. Ebbesen

Johan Hjelm


cgra@risoe.dtu.dk

christoph.graves@gmail.com

Oct. 11th, 2011

220th ECS Meeting

Boston, MA



Risø DTU


National Laboratory for Sustainable Energy

Outline


- Introduction + Purpose
- Experimental
- Results + Modeling
- Applications
- Conclusions

Introduction + Purpose

- Solid oxide cells promise economical + efficient sustainable energy conversion




Introduction + Purpose



Economical energy storage is ultimately needed to scale up renewable energy to meet a significant fraction of demand

High temp. co-electrolysis of $\text{H}_2\text{O} + \text{CO}_2$


- makes very efficient use of electricity + heat (near-100% electricity-to-syngas efficiency)
- provides high reaction rates
- directly produces syngas (CO/H_2 mixture) for use in conventional catalytic fuel synthesis reactors.



[C. Graves, S.D. Ebbesen, M. Mogensen, K.S. Lackner, *Renewable and Sustainable Energy Reviews* 15 (2011) 1-23]


Electrolysis cells

Intermittent electricity → hydrocarbon fuels



Reversible fuel cells



Intermittent electricity → hydrocarbon fuels + on-demand electricity



Introduction + Purpose


Solid oxide cells

- High performance for reversible reactions
 - Oxidation of $\text{H}_2/\text{CO}/\text{CH}_4$
 - Reduction of $\text{H}_2\text{O}/\text{CO}_2$
- Important goal is improving long-term durability



From: **Graves C**, Ebbesen SD, and Mogensen M, "Co-electrolysis of CO_2 and H_2O in Solid Oxide Cells: Performance and Durability," *Solid State Ionics* 192(1): p. 398-403 (2011).


Importance of current density



Fuel production economics is promising...

- Re. choice of "safe" and "harsh" current densities:
- *Knibbe, Traulsen, Hauch, Ebbesen, Mogensen 2010*
doi: 10.1149/1.3447752
 - *Graves, Ebbesen, Mogensen 2010*
doi: 10.1016/j.ssi.2010.06.014
 - *Ebbesen, Graves, Hauch, Jensen, Mogensen 2010*
doi: 10.1149/1.3464804
 - *Ebbesen & Mogensen 2010, doi: 10.1149/1.3455882*
 - *Xiufu Sun's talk tomorrow*

Importance of current density & capacity factor



Introduction + Purpose

Degradation of cell components is related to voltage across each component

- Fuel cell mode: too high anodic overpotential for $\text{Ni} \rightarrow \text{NiO}$
- Electrolysis mode: too high anodic overpotential for oxygen electrode \rightarrow microstructural degradation at interface with electrolyte

Normally, measuring overpotentials requires a reference electrode

- Here we demonstrate calculation of component-wise overpotentials (e.g. across each electrode and the electrolyte) for fuel cell + electrolysis polarization
 - without using a reference electrode
 - by careful measurement + analysis of impedance data
 - Also facilitates study of electrode kinetics


See also recent work by Leonide and coworkers:

Leonide A, Apel Y, and Ivers-Tiffée E, ECS Transactions, (2009). 19(20): 81-109.

A. Leonide et al., Journal of Power Sources, (2011). 196(17): 7343-7346.

Experimental


- Test set-up similar to
- Cell type:
 - Most measurements on Ni-YSZ/YSZ/CGO/LSC (16 cm²)
 - LSC oxygen electrode chosen because its impedance response has less overlap with other impedance processes (facilitates fitting impedance data)
- Test conditions: (impedance data measured at)
 - 650 – 850 °C
 - Varying H₂/CO/H₂O/CO₂ compositions to fuel electrode and pO_2 to ox. electrode
 - Varying current density



From: Ebbesen SD, **Graves C**, and Mogensen M, Production of Synthetic Fuels by Co-Electrolysis of Steam and Carbon Dioxide. International Journal of Green Energy, (2009). 6(6): p. 646 – 660.

Results



- Fuel cell mode – impedance measured under polarization



750 °C,
 $H_2/H_2O=97/3$,
 ox.el.=air


Results

- Reversible – impedance measured under polarization




Results

- Impedance measured under polarization




R_S is affected by temperature changes e.g. heating especially during fuel cell polarization



Using electrolyte conductivity activation energy of 0.8-0.9 eV for R_S , ΔT accounts for ΔR_S , approximately (calculated ΔT is slightly higher than measured ΔT ; thermocouple is ~1mm from electrolyte which can account for this)

Results


- Those were “fixed oven temperature” measurements
- The heating/cooling upon polarization effects temperature activated processes e.g. electrode kinetics
- This effect can be compensated for by using R_S as a temperature indicator and adjusting the oven temperature at each load setting, to obtain “fixed cell temperature” (fixed R_S) measurements:



750 °C,
 $H_2/H_2O=97/3$,
ox.el=air


Modeling the impedance data

- To quantify resistance contributions from each cell component, the impedance data must be carefully modeled
- Equivalent circuits or models based on chemical/physical processes
- Today all results used an equivalent circuit based on a previous equivalent circuit model established for Ni-YSZ/YSZ/LSM-YSZ type cells, now with a Gerischer element for oxygen electrode; we are also fitting to a model without circuit elements
- The low-frequency inductive loop observed at high current densities/overpotentials in both fuel cell & electrolysis modes has been speculated as various adsorption/surface layer processes. It affects quantifying the gas concentration process and should be included in the model



Modeling the impedance data

- Co-electrolysis – impedance measured under polarization




800 °C,
co-electrolysis
90%-reactants
(CO₂+H₂O),
ox.el.=O₂

Modeling the impedance data

- Co-electrolysis – impedance measured under polarization

Break down of cell resistance



800 °C,
co-electrolysis
90%-reactants
($\text{CO}_2 + \text{H}_2\text{O}$),
ox.el. = O_2

Calculating overpotential curves from fitted data


Meaning of $R_{X,EIS}$ vs i



$R_{EIS} = dU/di$ (local slope of an i - U curve)

To recreate an i - U curve, $dU = R_{EIS} \cdot di$, so integrate,
or numerically each $U_n = U_{n-1} + R_{EIS,n} \cdot (i_n - i_{n-1})$


Since we have a limited number of data points, use a fit (spline) to i - R curves

What does it look like? Examples





Break down of overpotentials






800 °C,
co-electrolysis
90%-reactants
($\text{CO}_2 + \text{H}_2\text{O}$),
ox.el. = O_2

Added to OCV to obtain
calculated i - U curve


Calculating overpotential curves from fitted data

Overlaid on measured i-U curve → agreement
(it had better agree if the method works 😊)





Reversible
polarization
- asymmetry



800 °C,
 $\text{H}_2/\text{H}_2\text{O}=50/50$,
ox.el.= O_2

Further considerations

- Effect of number data points (errors that arise)
- Effect of level of detail of model (errors)

Applications

- Overpotential vs time (degradation)
- Obtaining electrode kinetics parameters
- Connecting/reconciling DC and AC measurements (shown in earlier slide)
- Determine safe operating conditions (avoiding Ni/NiO)
- Comparing with 3-electrode measurements to study ref. electrode effects

Conclusions

- Analysis method demonstrated for electrolysis + fuel cell operation
 - careful measurement + analysis of impedance data obtained on full cells
→ calculate overpotential-current curves
- Isothermal i-U measurements obtained
 - and procedure developed
 - enables more meaningful study of transport/kinetics parameters
- Method being applied to long-term durability tests to calculate overpotential across each component during testing (observe evolution of overpotentials) and correlate with cell degradation

Acknowledgements

- Xiufu Sun for some of the measurements
- Energinet.dk
- SERC.dk
- Topsoe Fuel Cell

Thank you!