



Dynamic flow method to study the CO₂ loading capacity of amino acid salt solutions

Lerche, Benedicte Mai; Stenby, Erling Halfdan; Thomsen, Kaj

Publication date:
2011

Document Version
Publisher's PDF, also known as Version of record

[Link back to DTU Orbit](#)

Citation (APA):

Lerche, B. M., Stenby, E. H., & Thomsen, K. (2011). *Dynamic flow method to study the CO₂ loading capacity of amino acid salt solutions*. Poster session presented at 25th European Symposium on Applied Thermodynamics, Saint Petersburg, Russian Federation.

General rights

Copyright and moral rights for the publications made accessible in the public portal are retained by the authors and/or other copyright owners and it is a condition of accessing publications that users recognise and abide by the legal requirements associated with these rights.

- Users may download and print one copy of any publication from the public portal for the purpose of private study or research.
- You may not further distribute the material or use it for any profit-making activity or commercial gain
- You may freely distribute the URL identifying the publication in the public portal

If you believe that this document breaches copyright please contact us providing details, and we will remove access to the work immediately and investigate your claim.

Dynamic flow method to study the CO₂ loading capacity of amino acid salt solutions




Lerche B. M., Stenby E. H., Thomsen K.

CERE (Center for Energy Resources Engineering), Department of Chemical and Biochemical Engineering, Technical University of Denmark. In collaboration with DONG Energy & Vattenfall




CO₂ capture from flue gas by chemical absorption




Absorber: The CO₂ in the flue gas is chemically bound to the solvent (typically a solution of amines) and the cleaned gas is emitted to the air.

Desorber: The CO₂ loaded solvent (Rich amine) is heated to ~120 °C, whereby the CO₂ is released. The solvent (Lean amine) is circulated back to the absorber for another round of CO₂ capture. The pure CO₂ product from the desorber is compressed and sent to storage.



Mono-ethanolamine (MEA)
The amine most widely used for CO₂ capture




General structure of an amino acid

The amines normally used for CO₂ capture (such as MEA) entails both economical and environmental complications.

Amino acid salt solutions are promising new types of solvents for CO₂ capture.

Experimental set-ups used for studying CO₂ absorption by amino acid salt solutions

Dynamic & Analytical set-up (Dynamic flow set-up)




A gas mixture, containing approximately 10% CO₂ is continuously bubbled through the solvent, at a total pressure very close to atmospheric pressure.

The effluent stream is analyzed for its concentration of CO₂, using infrared (IR) spectroscopy.

The amount of CO₂ absorbed, is found by integrating over time, the concentration of CO₂ in the effluent stream.

Static & Synthetic set-up



A known amount of CO₂ is put into the gas cylinder. The experiment is started by opening the valve between the gas cylinder and the cell (A) containing the solvent.

The amount of CO₂ absorbed is measured indirectly:


The volume of the gas phase at equilibrium is found using the camera (C) with monitor (I).

Knowing the density of CO₂ gas at equilibrium conditions, the mass of CO₂ absorbed is calculated:

$$Mass_{CO_2 \text{ absorbed}} = Mass_{CO_2 \text{ added}} - Mass_{CO_2 \text{ gas phase at equilibrium}}$$

[José M. S. Fonseca, Ph.D. Thesis, CERE -Centre for Energy Resources Engineering Department of Chemical and Biochemical Engineering, Technical University of Denmark, 2010].

Categorization of experimental methods used for measuring CO₂ gas absorption



Dynamic : A continuous flow of gas into the cell is maintained during the experiment.

Static: The cell is filled with a known amount of gas, at the start of the experiment.

Analytical : The composition of the phases at equilibrium, are determined analytically.

Synthetic: The composition of the phases at equilibrium are based on indirect measurements, such as pressure, temperature, phase volumes and densities, which are subsequently used in calculations involving material balances.

Using the dynamic flow set-up to study CO₂ absorption of 4 amino acid salt solutions

1. Validation of the dynamic flow set-up with MEA




Figure 1: Validation of the dynamic flow set-up using aqueous solutions of (MEA) with concentrations between 2-8 molal. The experimental conditions were 40 °C, partial pressure of CO₂ ~ 10 kPa, and total pressure ~ 100 kPa.


The obtained data were validated against calculations of the Extended UNIQUAC thermodynamic model [Faramarzi et al. Fluid Phase Equilibria (2009)].

MEA represents a benchmark solution to which all new solvent will be compared.

Testning 4 amino acids

CO₂ absorption by aqueous solutions of the potassium salt of the 4 amino acids: L-lysine, glycine, taurine and L-proline.

Figure 2 & 3: The amino acid salt solutions were tested over the concentration range 2-7 molal. The figures show similar results for MEA. The experimental conditions were: 40°C, partial pressure of CO₂ ~ 10 kPa, and total pressure ~ 100 kPa.



2. CO₂ loading capacity




Figure 2: Loading capacity (mol CO₂/mol amine) for the 4 amino acid salt solutions, as well as for MEA, over the concentration range 2-7 molal. The unit, mol CO₂/mol amine is the typically way of presenting CO₂ absorption ability.

3. CO₂ capacity




Figure 3: Capacity (mol CO₂/Kg solution) for the 4 amino acid salt solutions, as well as for MEA, over the concentration range 2-7 molal. The unit, mol CO₂/Kg solution gives information about how much solution is needed to be circulated in the CO₂ capture system.

Conclusions:

- The amino acids tested show good CO₂ absorption ability when compared with MEA.

- L-Lysine offers high CO₂ absorption ability due to the 2 amino groups.

Future work:

- Further experiments with the dynamic flow set-up.
- The Static & Synthetic set-up presented above will be used to study the cyclic CO₂ absorption and regeneration ability of amino acid salt solutions.