



Assessment of Fast Radiographic Systems by the Constant Exposure Technique

Domanus, Joseph Czeslaw

Publication date:
1984

Document Version
Publisher's PDF, also known as Version of record

[Link back to DTU Orbit](#)

Citation (APA):
Domanus, J. C. (1984). *Assessment of Fast Radiographic Systems by the Constant Exposure Technique*. Danmarks Tekniske Universitet, Risø Nationallaboratoriet for Bæredygtig Energi. Risoe-M No. 2440

General rights

Copyright and moral rights for the publications made accessible in the public portal are retained by the authors and/or other copyright owners and it is a condition of accessing publications that users recognise and abide by the legal requirements associated with these rights.

- Users may download and print one copy of any publication from the public portal for the purpose of private study or research.
- You may not further distribute the material or use it for any profit-making activity or commercial gain
- You may freely distribute the URL identifying the publication in the public portal

If you believe that this document breaches copyright please contact us providing details, and we will remove access to the work immediately and investigate your claim.

**ASSESSMENT OF FAST RADIOGRAPHIC SYSTEMS
BY THE CONSTANT EXPOSURE TECHNIQUE**

**J. C. Domanus
Atlas Advanced Engineering Division**

Abstract. The constant exposure technique was applied to compare the radiographic image quality and relative speed of different fast radiographic systems. Conventional industrial X-ray films, exposed with lead intensifying screens, special fast film with fluorometallic screens as well as different brands of radiographic paper exposed both with fluorescent as well as fluorometallic screens were tested and compared. ISO wire IQI's and ASTM penetrameters were used together with 30-mm aluminium and 10-mm steel plates. For all the fast radiographic systems wire sensitivity better than 2% was obtained. The constant exposure technique proved to be adequate for the assessment of fast radiographic systems.

INIS Descriptors: INDUSTRIAL RADIOGRAPHY; PAPER; PHOTOGRAPHIC FILMS; QUALITY CONTROL; X-RAY RADIOGRAPHY

UDC 620.179.15 : 537.531

August 1984

Risø National Laboratory, DK-4000 Roskilde, Denmark

ISBN 87-550-1021-0

ISSN 0418-6485

Risø Repro 1984

CONTENTS	Page
1. INTRODUCTION	7
2. RADIOGRAPHIC PAPER	8
3. FAST X-RAY FILMS	8
4. COMPARIOSN OF X-RAY FILM AND RADIOGRAPHIC PAPER	9
5. X-RAY MACHINES	10
6. IMAGE QUALITY INDICATORS	11
7. OBJECTS EXAMINED	13
8. EXAMINATION PROCEDURE	13
9. RELATIVE SPEED AND KILOVOLTAGE	13
10. PROCESSING	18
11. RADIOGRAPHIC IMAGE QUALITY	21
11.1. Kodak systems	21
11.2. Agfa-Gevaert systems	26
11.3. Agfa-Gevaert fast systems	35
12. COMPARISON OF WIRE SENSITIVITIES	38
12.1. Kodak systems	45
12.2. Agfa Gevaert systems	46
13. COMPARISON OF RELATIVE SPEED AND KILOVOLTAGE	47
14. CONCLUSIONS	53
REFERENCES	54

ILLUSTRATIONS	Page
Fig. 1. Andrex 180-kV X-ray machine (self-rectified, single-tank) used for radiography of 30 mm Al plate	10
Fig. 2. Andrex 300-kV X-ray machine (self-rectified, single-tank) used for radiography of 10 mm Fe plate	11
Fig. 3. ISO wire IQI's and ASTM penetrameters for Al and Fe	12
Fig. 4. Comparison of relative speed and kilovoltage between Kodak Industrex systems at 30 mm Al	14
Fig. 5. Comparison of relative speed and kilovoltage between Kodak Industrex systems at 10 mm Fe	15
Fig. 6. Comparison of relative speed and kilovoltage between Agfa-Gevaert Structurix systems at 30 mm Al	16
Fig. 7. Comparison of relative speed and kilovoltage between Agfa Gevaert Structurix systems at 10 mm Fe	17
Fig. 8. Processing modes for Agfa-Gevaert Structurix RCF film	18
Fig. 9. Comparison of relative speed and kilovoltage between Agfa-Gevaert Structurix RCF film with FM screens at 30 mm Al	19
Fig. 10. Comparison of relative speed and kilovoltage between Agfa-Gevaert Structurix RCF film with FM screens at 10 mm Fe	20
Fig. 11. Percent radiographic quality for Kodak films and papers for 30 mm Al at 25 mAmin	22
Fig. 12. Percent radiographic quality for Kodak films and papers for 30 mm Al at 170 kV	23

Fig.13.	Percent radiographic quality for Kodak films and papers for 10 mm Fe at 100 mAmin	24
Fig.14.	Percent radiographic quality for Kodak films and 25 papers for 10 mm Fe and 215 kV	25
Fig.15.	Percent radiographic quality for Agfa-Gevaert 27 films and papers for 30 mm Al at 25 mAmin	27
Fig.16.	Percent radiographic quality for Agfa-Gevaert films and papers for 30 mm Al at 170 kV	28
Fig.17.	Percent radiographic quality for Agfa-Gevaert films and paper for 10 mm Fe at 100 mAmin	29
Fig.18.	Percent radiographic quality for Agfa-Gevaert films and paper for 10 mm Fe at 215 kV	30
Fig.19.	Percent radiographic quality for Agfa-Gevaert films and paper for 30 mm Al at 25 mAmin (for recommended processing)	31
Fig.20.	Percent radiographic quality for Agfa-Gevaert films and paper for 30 mm Al at 170 kV (for recommended processing)	32
Fig.21.	Percent radiographic quality for Agfa-Gevaert films and paper for 10 mm Fe at 100 mAmin (for recommended processing)	33
Fig.22.	Percent radiographic quality for Agfa-Gevaert films and paper for 10 mm Fe at 215 kV (for recommended processing)	34
Fig.23.	Percent radiographic quality for Agfa-Gevaert fast systems for 30 mm Al at 25 mAmin	35
Fig.24.	Percent radiographic quality for Agfa-Gevaert fast systems for 30 mm Al at 170 kV	36

Fig.25.	Percent radiographic quality for Agfa- Gevaert fast systems for 10 mm Fe at 100 mAmin	37
Fig.26.	Percent radiographic quality for Agfa- Gevaert fast systems for 10 mm Fe at 215 kV	38
Fig.27.	Image quality for 10 mm Al	39
Fig.28.	Image quality for 20 mm Al	40
Fig.29.	Image quality for 30 mm Al	41
Fig.30.	Image quality for 10 mm Fe	42
Fig.31.	Image quality for 20 mm Fe	43
Fig.32.	Image quality for 30 mm Fe	44

TABLES		PAGE
Table 1.	Comparison of relative speed for 30 mm Al at 170 kV	48
Table 2.	Comparison of relative speed for 10 mm Fe at 215 kV	49
Table 3.	Comparison of relative reduction in kilovoltage for 30 mm Al at 25 mAmin	50
Table 4.	Comparison of relative reduction of kilovoltage for 10 mm Fe at 100 mAmin	51

**ASSESSMENT OF FAST RADIOGRAPHIC SYSTEMS
BY THE CONSTANT EXPOSURE TECHNIQUE**

by

J. C. Domanus

**Atlas Advanced Engineering Division*
DK-2750 Ballerup, Denmark**

1. INTRODUCTION

The constant exposure technique, already described in [1] was investigated further in [2] and proved to be useful for such fast radiographic systems as radiographic paper used both with fluorescent as well as fluorometallic intensifying screens.

Recently, Agfa-Gevaert put on the market a new, fast X-ray film: Structurix RCF, high-contrast film, specially designed for use with fluorometallic intensifying screens.

This new, fast X-ray film together with fast radiographic papers was described in [3].

The constant exposure technique seems especially suitable for making comparisons between different radiographic systems and was therefore used for the assessment of the fast radiographic systems mentioned above.

* Work performed under contract with Risø National Laboratory.

2. RADIOGRAPHIC PAPER

The present comparisons of various fast radiographic systems was made, using the following radiographic papers, available now on the market:

- Kodak Industrex Instant 600, Rapid 620 and 700 papers, used with Kodak fluorescent F1 (high-speed, high-contrast) and F2 (smaller intensification, lower contrast) Industrex intensifying screens.
- Agfa-Gevaert Structurix IC paper used with a fluorescent IC screen Type II and with fluorometallic RCF screen.

Both Kodak as well as Agfa-Gevaert radiographic papers were processed in their respective automatic processors, previously described in [4].

The radiographic paper can be used both with fluorescent and with fluorometallic screens. This was proved and reported in [5]. This fast radiographic system was therefore also included into the present assessment.

3. FAST X-RAY FILMS

The above-mentioned Agfa-Gevaert Structurix RCF film was used with RCF fluorometallic screens (FM). This film is sensitive to X- and gamma-rays, UV-, violet and blue rays, and to rays emitted by the fluorometallic screens. The spectral sensitivities of Structurix IC paper, RCF film and FM screens was reproduced in [5].

Agfa-Gevaert allows the processing of the RCF film in the same manner as all other Structurix films. When using conventional manual processing the G 127 developer (concentration: 1 part of G 127 + 4 parts of water) is to be used for developing at 20°C for 5 min. Rapid processing is also possible and even recommended. For rapid manual processing the G 127 developer in (1 + 1) concentration is to be used at 35°C for 45 s (with

continuous agitation). For rapid machine processing the G 127/G 135 developers are to be used at 42°C. As no Structurix automatic machine processors were available in Denmark, some automatic processing of the RCF film was performed using the Rapiline 63 processor, made available for that purpose by the Agfa-Gevaert A/S in Glostrup, Denmark. In this automatic processor the RCF film was developed at 35°C for 32 s in a (1 + 3) concentrated G 137 developer. This automatic processing gave, however, very inconsistent results and therefore was not used further.

Thus the RCF film was normally developed for 5 min at 20°C in the (1 + 4) G 127 developer and for 45 s at 35°C in the (1+1) G 127.

For the sake of comparison two brands of the conventional industrial fast X-ray films were used: the Kodak Industrex D and Agfa-Gevaert Structurix D 10. Both were used with 0.05 + 0.10 mm lead intensifying screens (above 50 kV) or without screens (below 50 kV). They were manually processed: the Kodak D film in the DX-80 developer for 4 min at 20°C (1+4 concentration) and the Agfa-Gevaert D10 film for 5 min at 20°C in the G 127 developer (1 + 5 concentration).

4. COMPARISON BETWEEN X-RAY FILM AND RADIOGRAPHIC PAPER

Comparisons between X-ray film and paper were already previously made [6,7] using radiographic papers available at that time. In the present report the assessment will be made using radiographic papers mentioned in 2 above.

All the above mentioned investigations made with radiographic paper and fast X-ray films have shown the following advantages of those fast radiographic systems:

- Shorter exposure times due to the higher speed of the system.

- Lower material costs for paper radiography.
- Shorter processing times, especially with automatic processors.
- Lower labor costs due to shorter exposure and processing times.
- Lower equipment costs due to lower kilovoltages in use.
- Easier radiation protection due to lower kilovoltages in use.

5. X-RAY MACHINES

The investigation was performed using Andrex 180 and 300 kV self-rectified, single-tank machines.

Fig. 1 shows the 180 kV machine used for radiography of the 30-mm Al plate, whereas on fig. 2 the 300 kV machine is shown, used for radiography of the 10-mm Fe plate.




Fig.1. Andrex 180 kV X-ray machine (self-rectified, single-tank) used for radiography of the 30-mm Al plate




Fig.2. Andrex 300 kV X-ray machine (self-rectified, single-tank) used for radiography of 10-mm Fe plate

6. IMAGE QUALITY INDICATORS

Two types of image quality indicators were used: ISO wire IQI's and ASTM penetrameters. The relative merits and disadvantages of using those two systems were discussed in [8,9], whereas in [2] details about the IQI's are given.

In fig. 3 the ISO wire IQI's and ASTM penetrameters used for radiography of Al and Fe plates are shown. As a rule the 10 to 16 wire IQI's were used for all thicknesses of the plates under examination. For a 10-mm plate 0.1, 0.2 and 0.4-mm penetrameters were used, whereas for 30 mm - 0.3, 0.6 and 1.2-mm penetrameters were necessary.




Fig.3. ISO wire IQI's and ASTM penetrameters for Al and Fe

7. OBJECTS EXAMINED

A 30-mm thick Al and a 10 mm Fe plate were used together with the IQI's described above. They were shown in figs. 1 and 2.

8. EXAMINATION PROCEDURE

The examination procedure by the constant exposure technique was as follows:

For the slowest X-ray film (Kodak Industrex SR and Agfa-Gevaert D2) kilovoltage giving a film density of $D_f = 2.5$ was chosen for an exposure of 25 mAmin for 30 mm Al and 100 mAmin for 10 mm Fe. Those respective kilovoltages were 170 (for Al) and 215 kV (for Fe).

Thereafter, each film and paper was exposed at those constant exposures (25 mAmin for Al and 100 mAmin for Fe) so as to reach a film $D_f = 2.5$ or paper $D_p = 1.0$ density by lowering the kilovoltage accordingly.

Thus a comparison is possible of the relative decrease of kilovoltage, which gives the same density (D_f or D_p), for the same exposure (mAmin).

To be able to calculate the relative speed of different film or paper systems a comparison was made at constant kilovoltages (170 kV for Al and 215 kV for Fe). There at those kilovoltages exposures were made so as to reach densities of $D_f = 2.5$ or $D_p = 1.0$. By comparing different exposures (in mAmin) necessary to obtain those film/paper densities (at constant kilovoltages) relative speed can be directly determined.

9. RELATIVE SPEED AND KILOVOLTAGE

The results reached by using the examination procedure described above are presented in fig. 4 for Kodak Industrex

systems and 30 mm Al, whereas fig. 5 shows similar results for 10 mm Fe.




Fig.4. Comparison of relative speed and kilovoltage for Kodak Industrex systems at 30 mm Al




Fig.5. Comparison of relative speed and kilovoltage between Kodak Industrex systems at 10 mm Fe

A similar comparison performed for Agfa-Gevaert Structurix systems is shown in fig. 6 for 30 mm Al and on fig. 7 for 10 mm Fe.




Fig.6. Comparison of relative speed and kilovoltage between Agfa-Gevaert Structurix systems at 30 mm Al

AGFA GEVAERT STRUCTURIX **10 mm Fe**




Fig.7. Comparison of relative speed and kilovoltage between Agfa-Gevaert Structurix systems at 10 mm Fe

The RCF film was processed manually (M) at different developing temperatures and times and automatically (A). Different developer concentrations were thereby used. Those processing modes are shown in fig. 8.

Mode	Processing	Concen- tration	
Manual	20°C; 5 min	1 + 5	M1
	35°C; 45 s	1 + 5	M2
	20°C; 5 min	1 + 4	M3
	35°C; 45 s	1 + 4	M4
	20°C; 5 min	1 + 1	M5
	35°C; 45 s	1 + 1	M6
Automat.	35°C; 32 s	1 + 3	A

Fig.8. Processing modes for Agfa-Gevaert Structurix RCF film

10. PROCESSING

As mentioned above, all conventional X-ray films were manually processed and the radiographic papers were processed in automatic processors according to procedures recommended by their manufacturers.

Different processing modes were tried for the Agfa-Gevaert Structurix RCF film used with FM screens. Both manual as well as automatic processing was tested, using different developing temperatures, time and developer concentration. The influence of the processing mode on the relative speed and kilovoltage is shown in figs. 9 and 10.

AGFA GEVAERT STRUCTURIX
RCM - FM
30 mm Al




Fig.9. Comparison of relative speed and kilovoltage between Agfa-Gevaert Structurix RCP film with FM screens at 30 mm Al

AGFA GEVAERT STRUCTURIX

RCM-FM

10 mm Fe




Fig.10. Comparison of relative speed and kilovoltage for Agfa-Gevaert Structurix RCF film with FM screens at 10 mm Fe

As explained in 3 above for manual processing, modes M3 and M6 are recommended by the film manufacturer. Although, the M6 mode, requiring a high concentration of the developer (1 + 1) and a relatively high temperature (35°C), gives a higher relative speed and permits the use of lower kilovoltage, is not practical and can hardly be recommended unless higher speed is of primary importance.

As can be seen (see figs. 9 & 10) there is practically no difference in relative speed or kilovoltage when using either the manual M3 or automatic A processing mode, whereas the use of the manual M6 mode can increase the speed by about 50%.

11. RADIOGRAPHIC IMAGE QUALITY

To be able to judge to what extent the fast radiographic systems can be used, the radiographic image quality obtained with those systems was tested. For that purpose the equipment described above, indicators and test objects were used.

Each radiograph of an Al or Fe plate containing the images of the wire IQI's and ASTM penetrameters was visually examined by three persons and the results of their assessment were presented in the previously adapted form of diagrams [2,3,5,8,9], on which the finding of each observer is marked by a black line, whereas the dotted strip signifies that all three persons were of the same opinion. The results obtained before were supplemented with those obtained during the present investigation using Agfa-Gevaert D 10 and RCF films and IC paper with fluorometallic screens.

11.1. Kodak systems

The results of the investigation performed with Kodak films and papers were already presented before in [2]. The percent radiographic quality is presented in figs. 11 and 12 for 30 mm Al and in figs. 13 and 14 for 10 mm Fe.

Apparatus	ISO IQI		30 mm Al														ASTM penetra- meter										
			25 mAmin = const.																								
			FILM OR PAPER																								
	SR	DR	M	A	C	D	700	600	620	700	600	620	%	Level													
	SCREEN																										
0.05+0.1 Pb	0.05+0.1 Pb	0.05+0.1 Pb	0.05+0.1 Pb	0.05+0.1 Pb	0.05+0.1 Pb	F2	F2	F2	F1	F1	F1																
kV																											
Nr.	%	170		160		120		85		77		70		74		75		68		64		63		61			
		ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM		
Andrex 180	8	1.33																							2.8	4-1T, 2-4T	
	11	1.07																							2.0	3-2T	
	12	0.80																							1.6	2-1T, 1-4T	
	13	0.67																							1.0	1-2T	
	14	0.53																							0.7	1-1T	
	15	0.42																									
	16	0.33																									

Fig.11. Percent radiographic quality for Kodak films and papers for 30 mm Al at 25 mAmin

Apparatus	ISO IQI		30 mm Al														ASTM penetra- meter			
			170 kV = const.																	
			FILM OR PAPER																	
			SR	DR	M	A	C	D	700	600	620	700	600	620						
	Nr.	%	SCREEN																%	Level
0.05+0.1 Pb			0.05+0.1 Pb	0.05+0.1 Pb	0.05+0.1 Pb	0.05+0.1 Pb	0.05+0.1 Pb	F2	F2	F2	F1	F1	F1							
mAmin																				
25			18.75	6.67	1.50	1.24	0.57	0.73	0.83	0.31	0.13	0.08	0.04							
ISO			ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM			
Andrex 180																		2.8	4-1T; 2-4T	
																		2.0	2-2T	
	9	1.67																1.4	2-1T; 1-4T	
	10	1.33																1.0	1-2T	
	11	1.07																0.7	1-1T	
	12	0.83																		
	13	0.67																		
	14	0.53																		
15	0.42																			
16	0.33																			

Fig.12. Percent radiographic quality for Kodak films and papers for 30 mm Al at 170 kV

Apparatus		ISO IQI		10 mm Fe																		ASTM penetra- meter	
				100 mAmin = const.																			
				FILM OR PAPER																			
				SR	DR	M	A	C	D	700	600	620	700	600	620								
Nr.	%	SCREEN																		% Level			
		0.05+0.1 Pb	0.05+0.1 Pb	0.05+0.1 Pb	0.05+0.1 Pb	0.05+0.1 Pb	0.05+0.1 Pb	F2	F2	F2	F1	F1	F1										
		kV																					
		215	190	165	135	130	120	127	127	117	112	112	108										
		ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM		
Andrex 300	10	4.0																				4.0	4-2T
	11	3.2																				2.8	4-1T; 2-4T
	12	2.5																				2.0	2-2T
	13	2.0																				1.4	2-1T; 1-4T
	14	1.6																				1.0	1-2T
	15	1.25																				0.7	1-1T
16	1.0																						

Fig.13. Percent radiographic quality for Kodak films and papers for 10 mm Fe at 100 mAmin

Apparatus		ISO IQI		10 mm Fe												ASTM penetra- meter		
				215 kV=const.														
				FILM OR PAPER														
				SR	DR	M	A	C	D	700	600	620	700	600	620			
Nr.	%	SCREEN												%	Level			
		0.05+0.1 Pb	0.05+0.1 Pb	0.05+0.1 Pb	0.05+0.1 Pb	0.05+0.1 Pb	0.05+0.1 Pb	F2	F2	F2	F1	F1	F1					
		mAmin																
		100	80	30	7.5	6	3	4.5	4.5	1.67	1.17	0.82	0.33					
		ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM			
Andrex 300	10	4.0															4.0	4-2T
	11	3.2															2.8	4-1T; 2-4T
	12	2.5															2.0	2-2T
	13	2.0															1.4	2-1T; 1-4T
	14	1.6															1.0	1-2T
	15	1.25															0.7	1-1T
	16	1.0																

Fig.14. Percent radiographic quality for Kodak films and papers for 10 mm Fe and 215 kV

11.2. Agfa-Gevaert systems

In the previous investigation [2] only the Agfa-Gevaert Structurix IC paper with IC II and FM screens were tested. Now those tests were supplemented with the use of other brands of the Structurix film. The RCF film was also investigated using different processing modes.

The percent radiographic quality for all those systems is presented in figs. 15 and 16 for 30 mm Al and figs. 17 and 18 for 10 mm Fe.

As mentioned in 3 and 10 above, the RCF film manufacturer recommends normal processing for this film brand in (1 + 4) concentrated developer at 20°C for 2 min (M3) or in (1 + 1) developer at 35°C for 45 s (M6). An automatic processing in (1 + 3) developer at 32 s is also recommended (A).

A comparison containing only those processing modes for the RCF film is shown in figs. 19 and 20 for 30 mm Al and figs. 21 and 22 for 10 mm Fe.

Fig.15. Percent radiographic quality for Agfa-Gevaert films and paper for 30 mm Al at 25 mAmin




Fig.16. Percent radiographic quality for Agfa-Gevaert films and paper for 30 mm Al at 170 kV

ISO IQI		10 mm Fe														ASTM penetra-meter			
		100 mAmin = const.																	
Apparatus		FILM OR PAPER																	
		D2	D4	D5	D7	D10	RCF	RCF	RCF	RCF	RCF	RCF	RCF	IC	IC				
		SCREEN																	
		0.05+0.1 Pb	0.05+0.1 Pb	0.05+0.1 Pb	0.05+0.1 Pb	0.05+0.1 Pb	FM	FM	FM	FM	FM	FM	FM	FM	ICII				
		kV																	
		210	153	141	131	118	114	115	112.5	111.5	112.5	110.75	113.5	110	112				
		DEVELOPER																	
		G127	G127	G127	G127	G127	G127	G127	G127	G127	G127	G127	G137	G126	G126				
		TEMPERATURE °C																	
		20	20	20	20	20	20	35	20	35	20	35	35	20	20				
TIME																			
5 min	5 min	5 min	5 min	5 min	5 min	45 s	5 min	45 s	5 min	45 s	32 s	2 cm/s	2 cm/s						
CONCENTRATION																			
1+5	1+5	1+5	1+5	1+5	1+5	1+5	1+4	1+4	1+1	1+1	1+1	1+3	1+0	1+0					
ISO ASTM	ISO ASTM	ISO ASTM	ISO ASTM	ISO ASTM	ISO ASTM	ISO ASTM	ISO ASTM	ISO ASTM	ISO ASTM	ISO ASTM	ISO ASTM	ISO ASTM	ISO ASTM	ISO ASTM					
Andrex 300	10	40																	
	11	32																	
	12	25																	
	13	20																	
	14	16																	
	15	12.5																	
16	10																		

Fig.17. Percent radiographic quality for Agfa-Gevaert films and paper for 10 mm Fe at 100 mAmin

Apparatus		ISO	IQI	10 mm Fe																ASTM penetra-meter	
				215 kV = const.																	
				FILM OR PAPER																	
				D2	D4	D5	D7	D10	RCF	RCF	RCF	RCF	RCF	RCF	RCF	RCF	IC	IC			
Nr.	%	SCREEN																%	Level		
		0.05+0.1 Pb	0.05+0.1 Pb	0.05+0.1 Pb	0.05+0.1 Pb	0.05+0.1 Pb	FM	FM	FM	FM	FM	FM	FM	FM	FM	ICII					
		mAmin																			
		90	20	12.5	6.8	2.1	0.73	0.75	0.60	0.60	0.54	0.41	0.66	0.56	0.66						
		DEVELOPER																			
		G127	G127	G127	G127	G127	G127	G127	G127	G127	G127	G127	G137	G126	G126						
		TEMPERATURE °C																			
		20	20	20	20	20	20	35	20	35	20	35	35	20	20						
		TIME																			
		5 min	5 min	5 min	5 min	5 min	5 min	45 s	5 min	45 s	5 min	45 s	32 s	2 cm/s	2 cm/s						
CONCENTRATION																					
1+5	1+5	1+5	1+5	1+5	1+5	1+5	1+4	1+4	1+1	1+1	1+3	1+0	1+0								
ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM		
10	4.0																	10	1.1		
11	3.2																	2.8	4.1 2.4		
12	2.5																	2.0	2.3		
13	2.0																	1.4	2.1 1.4		
14	1.6																	1.0	1.2		
15	1.25																	0.7	1.1		
16	1.0																				

Fig.18. Percent radiographic quality for Agfa-Gevaert films and paper for 10 mm Fe at 215 kV.

Apparatus		30 mm Al										ASTM penetra-meter	
		25m Amin = const.											
ISO IQI		FILM OR PAPER											
		D2	D4	D5	D7	D10	RCF	RCF	RCF	IC	IC		
		SCREEN											
		0.05-0.1 Pb	0.05-0.1 Pb	0.05-0.1 Pb	0.05-0.1 Pb	0.05-0.1 Pb	FM	FM	FM	FM	ICII		
		kV											
		170	106	94	91	75	67.5	64	67.5	62.5	66		
		DEVELOPER											
		G127	G127	G127	G127	G127	G127	G127	G137	G126	G126		
Nr. %		TEMPERATURE °C										% Level	
		20	20	20	20	20	20	35	35	20	20		
		TIME											
		5 min	5 min	5 min	5 min	5 min	5 min	45 s	32 s	2 cm/s	2 cm/s		
		CONCENTRATION											
		1+5	1+5	1+5	1+5	1+5	1+4	1+1	1+3	1+0	1+0		
		ISO ASTM	ISO ASTM	ISO ASTM	ISO ASTM	ISO ASTM	ISO ASTM	ISO ASTM	ISO ASTM	ISO ASTM	ISO ASTM		
Andrex 180												28	4-17 2-47
												28	2-37
												14	2-17 1-47
												10	1-27
												0.7	1-17
		</											

Fig.19. Percent radiographic quality for Agfa-Gevaert films and paper for 30 mm Al at 25 mAmin (for RCF recommended processing)




Fig.21. Percent radiographic quality for Agfa-Gevaert films and paper for 10 mm Fe at 100 mAmin (for RCF recommended processing)




Fig.22. Percent radiographic quality for Agfa-Gevaert films and paper for 10 mm Fe at 215 kV (for RCF recommended processing)

11.3. Agfa-Gevaert fast systems

The comparison between only the fast systems (D 10 and RCF films and IC paper) is made in figs. 23 and 24 for 30 mm Al and figs. 25 and 26 for 10 mm Fe.




Fig.23. Percent radiographic quality for Agfa-Gevaert fast systems for 30 mm Al at 25 mAmin

Apparatus	30 mm Al										ASTM penetra-meter			
	170 kV = const.													
	FILM OR PAPER													
	D10	RCF	RCF	RCF	RCF	RCF	RCF	RCF	IC	IC				
	SCREEN										% Level			
	005+0.1 Pb	FM	FM	FM	FM	FM	FM	FM	FM	ICII				
	mAmin													
	0.55	0.275	0.155	0.22	0.16	0.10	0.135	0.22	0.17	0.14				
	DEVELOPER													
	G127	G127	G127	G127	G127	G127	G127	G137	G126	G126				
TEMPERATURE °C														
20	20	35	20	35	20	35	35	20	20					
TIME														
5 min	5 min	45 s	5 min	45 s	5 min	45 s	32 s	2 cm/s	2 cm/s					
CONCENTRATION														
1+5	1+5	1+5	1+4	1+4	1+1	1+1	1+3	1+0	1+0					
ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM			
Andrex 180	12	1.33										20	4-17, 2-6T	
	11	1.07											20	2-2T
	10	0.80											14	2-1T, 1-4T
	13	0.63											10	1-2T
	14	0.50											07	1-1T
	15	0.40												
	16	0.33												

Fig.24. Percent radiographic quality for Agfa-Gevaert fast systems for 30 mm Al at 170 kV

Apparatus		Nr.		%		10 mm Fe										ASTM penetra- meter			
						100 mAmin = const.													
						FILM OR PAPER													
						D10	RCF	RCF	RCF	RCF	RCF	RCF	RCF	IC	IC				
Andrex 300		10		4.0		SCREEN										%		Level	
						0.05-0.1 Pb													
						FM	FM	FM	FM	FM	FM	FM	FM	FM	ICII				
						kV													
						118	114	115	112.5	111.5	112.5	110.75	113.5	110	112				
						DEVELOPER													
						G127	G127	G127	G127	G127	G127	G127	G137	G126	G126				
						TEMPERATURE °C													
						20	20	35	20	35	20	35	35	20	20				
								15		1.25		TIME							
5 min																			
45 s																			
CONCENTRATION																			
		16		1.0		1-5													
						1-5													
						1-5													
						1-4													
		15		1.25		1-4													
						1-4													
						1-1													
						1-1													
		14		1.6		1-3													
						1-3													
						1-0													
						1-0													
		13		2.0		ISO ASTM													
						ISO ASTM													
						ISO ASTM													
						ISO ASTM													
		12		2.5		ISO ASTM													
						ISO ASTM													
						ISO ASTM													
						ISO ASTM													
		11		3.2		ISO ASTM													
						ISO ASTM													
						ISO ASTM													
						ISO ASTM													
		10		4.0		ISO ASTM													
						ISO ASTM													
						ISO ASTM													
						ISO ASTM													

Fig.25. Percent radiographic quality for Agfa-Gevaert fast systems for 10 mm Fe at 100 mAmin

Apparatus		10 mm Fe										ASTM penetra-meter			
		215 kV = const.													
		FILM OR PAPER													
		D10	RCF	RCF	RCF	RCF	RCF	RCF	RCF	IC	IC				
Nr.	%	SCREEN										%	Level		
		0.05+0.1 Pb	FM	FM	FM	FM	FM	FM	FM	FM	ICII				
		mAmin													
		2.1	0.73	0.75	0.60	0.60	0.54	0.41	0.66	0.56	0.66				
		DEVELOPER													
		G127	G127	G127	G127	G127	G127	G127	G137	G126	G126				
		TEMPERATURE °C													
		20	20	35	20	35	20	35	35	20	20				
		TIME													
		5 min	5 min	45 s	5 min	45 s	5 min	45 s	32 s	2 cm/s	2 cm/s				
CONCENTRATION															
1+5	1+5	1+5	1+4	1+4	1+1	1+1	1+3	1+0	1+0						
ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM
10	4.0													4.0	2.7
11	3.2													2.8	4.1T, 2.4T
12	2.5													2.0	2.2T
13	2.0													1.4	2.1T, 1.4T
14	1.6													1.0	1.2T
15	1.25													0.7	1.1T
16	1.0														

Fig.26. Percent radiographic quality for Agfa-Gevaert fast systems for 10 mm Fe at 215 kV

12. COMPARISON OF WIRE SENSITIVITIES

In [8,9] the results obtained of the investigation of radiographic image quality found for different thicknesses of Al and Fe (10,20 and 30 mm) radiographed at different kilovoltages for Kodak fast systems and the Agfa-Gevaert IC/ICII paper were compared.

This was recently supplemented with the results obtained for Agfa-Gevaert fast systems (D10, RCF, IC/FM), as reported in [3].

The results of this investigation are presented in figs. 27, 28, 29 for Al and 30, 31 and 32 for Fe.

Apparatus	kV	ISO IQI		10 mm Al										ASTM penetra- meter	
				FILM OR PAPER											
		D10		RCF		RCF		IC		IC			Level		
		SCREEN													
		0		FM		FM		FM		ICII					
		DEVELOPER													
		G127		G127		G127		G126		G126					
		TEMPERATURE °C													
		20		20		35		20		20					
		TIME													
		5 min		5 min		45 s		2 cm/s		2 cm/s					
		CONCENTRATION													
1+5		1+4		1+1		1+0		1+0							
ISO		ASTM		ISO		ASTM		ISO		ASTM					
Balteau B 50	45	12	2.5									2.8	4-1T, 2-4T		
		13	2.0									2.0	2-2T		
		14	1.6									1.4	2-1T, 1-4T		
		15	1.25									1.0	1-2T		
		16	1.0									0.7	1-1T		
Balteau B 50	50	12	2.5									2.8	4-1T, 2-4T		
		13	2.0									2.0	2-2T		
		14	1.6									1.4	2-1T, 1-4T		
		15	1.25									1.0	1-2T		
		16	1.0									0.7	1-1T		
Andrex A 180	50	10	4.0										5.6	4-4T	
		11	3.2										4.0	4-2T	
		12	2.5										2.8	4-1T, 2-4T	
		13	2.0										2.0	2-2T	
		14	1.6										1.4	2-1T, 1-4T	
	70	15	1.25											1.0	1-2T
		16	1.0											0.7	1-1T
		70	10	4.0										5.6	4-4T
			11	3.2										4.0	4-2T
			12	2.5										2.8	4-1T, 2-4T
			13	2.0										2.0	2-2T
			14	1.6										1.4	2-1T, 1-4T
			15	1.25										1.0	1-2T
			16	1.0										0.7	1-1T
			SCREEN		0.05+01Pb										

Fig.27. Image quality for 10 mm Al

Apparatus	ISO IQI		20mm Al										ASTM penetra- meter	
			FILM OR PAPER											
			D10	RCF	RCF	IC	IC							
	kV	Nr.	%	SCREEN					% Level					
				0	FM	FM	FM	ICII						
				DEVELOPER										
				G127	G127	G127	G126	G126						
				TEMPERATURE °C										
				20	20	35	20	20						
				TIME										
				5min	5min	45 s	2 cm/s	2cm/s						
				CONCENTRATION										
1+5				1+4	1+1	1+0	1+0							
ISO				ASTM	ISO	ASTM	ISO	ASTM		ISO	ASTM	ISO	ASTM	
Balteau B 50	45	10	20											2.8 4-1T, 2-4T 2.0 2-2T 1.4 2-1T, 1-4T 1.0 1-2T 0.7 1-1T
		11	16											
		12	1.25											
		13	1.0											
		14	0.8											
		15	0.63											
	16	0.5												
	50	10	20											2.8 4-1T, 2-4T 2.0 2-2T 1.4 2-1T, 1-4T 1.0 1-2T 0.7 1-1T
		11	16											
		12	1.25											
		13	1.0											
		14	0.8											
15		0.63												
16	0.5													
Andrex A 180	70	10	20											2.8 4-1T, 2-4T 2.0 2-2T 1.4 2-1T, 1-4T 1.0 1-2T 0.7 1-1T
		11	16											
		12	1.25											
		13	1.0											
		14	0.8											
		15	0.63											
	16	0.5												
	SCREEN			0.05+0.1Pb										

Fig. 28. Image quality for 20 mm Al

Apparatus	kV	ISO IQI		10 mm Fe										ASTM penetra - meter	
				FILM OR PAPER											
				D10	RCF	RCF	IC	IC							
		Nr.	%	SCREEN										%	Level
				005+01Pb	FM	FM	FM	ICII							
				DEVELOPER											
				G127	G127	G127	G126	G126							
				TEMPERATURE °C											
				20	20	35	20	20							
				TIME											
				5 min	5min	45 s	2 cm/s	2cm/s							
				CONCENTRATION											
				1+5	1+4	1+1	1+0	1+0							
ISO	ASTM			ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM				
Andrex A 300	125			10	4.0										
		11	3.2												
		12	2.5											2.8	2-4T,4-1T
		13	2.0											2.0	2-2T
		14	1.6											1.4	1-4T, 2-1T
		15	1.25											1.0	1-2T
	150	16	1.0											0.7	1-1T
		10	4.0											4.0	4-2T
		11	3.2												
		12	2.5											2.8	2-4T,4-1T
		13	2.0											2.0	2-2T
		14	1.6											1.4	1-4T, 2-1T
	175	15	1.25											1.0	1-2T
		16	1.0											0.7	1-1T
		10	4.0											4.0	4-2T
		11	3.2												
		12	2.5											2.8	2-4T,4-1T
		13	2.0											2.0	2-2T
14	1.6											1.4	1-4T, 2-1T		
15	1.25											1.0	1-2T		
16	1.0											0.7	1-1T		

Fig. 30. Image quality for 10 mm Fe

Apparatus	kV	ISO IQI		20 mm Fe										ASTM penetra - meter	
				FILM OR PAPER											
				D10	RCF	RCF	IC	IC							
		Nr.	%	SCREEN										%	Level
				005+0.1Pb	FM	FM	FM	ICII							
				DEVELOPER											
				G127	G127	G127	G126	G126							
				TEMPERATURE °C											
				20	20	35	20	20							
				TIME											
				5 min	5 min	45 s	2 cm/s	2 cm/s							
CONCENTRATION															
1+ 5	1+ 4			1+ 1	1+ 0	1+ 0									
ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM						
Andrex A 300	150	9	2.5											2.8	2-4T, 4-1T
		10	2.0											2.0	2-2T
		11	1.6											1.4	1-4T, 2-1T
		12	1.25											1.0	1-2T
		13	1.0											0.7	1-1T
		14	0.8												
		15	0.63												
		16	0.5												
	175	9	2.5											2.8	2-4T, 4-1T
		10	2.0											2.0	2-2T
		11	1.6											1.4	1-4T, 2-1T
		12	1.25											1.0	1-2T
		13	1.0											0.7	1-1T
		14	0.8												
	200	9	2.5											2.8	2-4T, 4-1T
		10	2.0											2.0	2-2T
		11	1.6											1.4	1-4T, 2-1T
		12	1.25											1.0	1-2T
		13	1.0											0.7	1-1T
		14	0.8												
	225	9	2.5											2.8	2-4T, 4-1T
		10	2.0											2.0	2-2T
		11	1.6											1.4	1-4T, 2-1T
		12	1.25											1.0	1-2T
		13	1.0											0.7	1-1T
14		0.8													
250	9	2.5											2.8	2-4T, 4-1T	
	10	2.0											2.0	2-2T	
	11	1.6											1.4	1-4T, 2-1T	
	12	1.25											1.0	1-2T	
	13	1.0											0.7	1-1T	
	14	0.8													

Fig. 31. Image quality for 20 mm Fe

Apparatus	kV	ISO IQI		30 mm Fe										ASTM penetra - meter																																																																														
		Nr.	%	FILM OR PAPER											Level																																																																													
				D10		RCF		RCF		IC		IC																																																																																
				SCREEN																																																																																								
				005•01Pb		FM		FM		FM		ICII																																																																																
				DEVELOPER																																																																																								
				G127		G127		G127		G126		G126																																																																																
				TEMPERATURE °C																																																																																								
				20		20		35		20		20																																																																																
				TIME																																																																																								
				5 min		5 min		45 s		2 cm/s		2cm/s																																																																																
				CONCENTRATION																																																																																								
1+ 5		1+4		1+ 1		1+ 0		1+ 0																																																																																				
ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM	ISO	ASTM																																																																																			
Andrex A 300	200	8	21																																																																																									

Fig. 32. Image quality for 30 mm Fe

The present comparison is made for results obtained by the constant exposure method.

12.1. Kodak systems

Looking at the results obtained with aluminium at constant exposure (fig. 11) one can see that only the slowest films (SR, DR and M) show the finest wire sensitivity of 0.53%, whereas sensitivities obtained with such papers as 620/F2 and 700/F1 are equal to those obtained with faster films (A, C and D), i.e. 0.67% (one more wire seen on the radiographs).

Looking at the results obtained with aluminium at constant kilovoltage (fig.12) one can see that also here the finest wire sensitivity of 0.53% was reached for the slowest films (SR, DR and M). It decreases considerably for all other fast systems (e.g. for 700/F1 by 3 wires to 1.07%).

By comparing the results obtained by those two methods (constant exposure vs. constant kilovoltage) one can clearly see the advantages of the constant exposure method.

It is, however, remarkable that by both methods a wire sensitivity better than 2% was reached for all Kodak systems.

The results obtained with steel at constant exposure (fig.13) are very similar to those for aluminium. Here also the highest wire sensitivity of 1% was reached for the slowest films (SR, DR and M) and it was possible to reach equal sensitivity of 1.25 % for such papers as 620/F1 as for the faster films A and C (which are worse than the best one for slow films only by one wire). The faster film (D) showed a sensitivity that is worse by two wires (1.6%) which could be reached by all papers (except the 600/F1).

Results obtained with steel at constant kilovoltage show even a greater decrease in the wire sensitivity for faster systems (fig.14). Here only the slowest films (SR and DR) show the best sensitivity of 1%. The sensitivity of the fast systems deteriorates by 4 wires to 2.5% and only occasionally can reach 2%, as in the case of the D film and 700/F2 paper.

Also for steel the advantage of the constant exposure method has been confirmed.

12.2. Agfa-Gevaert systems

While comparing the results obtained for Agfa-Gevaert systems one will look in particular for the processing modes recommended by the manufacturer for the RCF/FM film (manual: M3 - concentration (1 + 4), developing at 20°C for 5 min; M6 - concentration (1 + 1), developing at 35°C for 45 s; automatic: A - concentration (1 + 3), developing at 35°C for 32 s).

From fig. 15 one can see that with aluminium at constant exposure the best wire sensitivity of 0.53% was reached for only the slowest films (D2 and D4), whereas for all the other systems only one less wire (0.67%) was seen.

As described in 12.1. above with aluminium at constant kilovoltage (fig.16) the wire sensitivity decreases considerably with the increase of the speed of the system. The best sensitivity of 0.53% was reached only for the slowest film (D2) and drops by 3 wires (to 1.07%) for the RCF film processed with the M3 and M6 mode and even to 1.33% for D10 film and IC paper.

As would be expected also here the advantage of the constant exposure technique was confirmed.

With steel at constant exposure (fig.17) the best wire sensitivity of 1.25% was reached for only the slowest D2 film (although 2 of 3 observers could see the 1% wire). The same high sensitivity could be reached by the RCP film (M6), whereas for all other systems a sensitivity poorer by only one wire (1.6%) was reached (except for IC/ICII - two wires, 2%).

With steel at constant kilovoltage (fig.18) again the same effect was observed as before: only the slowest film (D2) shows the finest wire sensitivity (1.25%) which thereafter decreases by two wires to 2% (except for IC/ICII - 3.2%).

For all Agfa-Gevaert Systems a wire sensitivity better than 2% could be reached both for Al and Fe (with the single exception of IC/ICII and Fe at constant kV).

13. COMPARISON OF RELATIVE SPEED AND KILOVOLTAGE

In 9 above, relative speed and kilovoltage were given separately for Kodak (figs.4 and 5) and Agfa-Gevaert (figs. 6 and 7) systems. The relative speed was calculated for 170 kV for Al and 215 kV for Fe, whereas the relative kilovoltage for 25 mAmin for Al and 100 mAmin for Fe. In all instances the comparison was made at constant film density of $D_f = 2.5$ and paper density of $D_p = 1.0$.

Now all Kodak and Agfa-Gevaert systems will be compared together. The result is shown in tables 1 and 2 for the relative speed and tables 3 and 4 for the relative reduction in kilovoltage.

Table 1. Comparison of relative speed for 30 mm Al at 170 kV

Film/paper	Screen	Relative speed
SR	0.05+0.10mm Pb	1
D2	0.05+0.10mm Pb	1
DR	0.05+0.10mm Pb	1.3
M	0.05+0.10mm Pb	3.7
D4	0.05+0.10mm Pb	4.55
D5	0.05+0.10mm Pb	6.94
D7	0.05+0.10mm Pb	13.5
A	0.05+0.10mm Pb	17
C	0.05+0.10mm Pb	20
600	F2	30
700	F2	34
D	0.05+0.10mm Pb	44
D10	0.05+0.10mm Pb	45.5
620	F2	81
RCP (M3)	PM	114
RCP (A)	PM	114
IC	PM	147
IC	IC II	180
RCP (M6)	PM	185
700	F1	192
600	F1	313
620	F1	625

Table 2. Comparison of relative speed for 10 mm Fe at 215 kV

Film/paper	Screen	Relative speed
SR	0.05+0.10mm Pb	1
D2	0.05+0.10mm Pb	1.11
DR	0.05+0.10mm Pb	1.25
M	0.05+0.10mm Pb	3.33
D4	0.05+0.10mm Pb	5
D5	0.05+0.10mm Pb	8
A	0.05+0.10mm Pb	13
D7	0.05+0.10mm Pb	15
C	0.05+0.10mm Pb	17
700	F2	22
600	F2	22
D	0.05+0.10mm Pb	33
D10	0.05+0.10mm Pb	48
620	F2	60
700	F1	85
600	F1	122
RCF (A)	FM	151
IC	IC II	151
RCF (M3)	FM	166
IC	FM	178
RCF (M6)	FM	244
620	F1	303

Table 3. Comparison of relative reduction in kilovoltage for 30 mm Al at 25 mAmin

Film/paper	Screen	% kV
SR	0.05+0.10mm Pb	100
D2	0.05+0.10mm Pb	100
DR	0.05+0.10mm Pb	94
M	0.05+0.10mm Pb	71
D4	0.05+0.10mm Pb	62.4
D5	0.05+0.10mm Pb	55.3
D7	0.05+0.10mm Pb	53.5
A	0.05+0.10mm Pb	50
D	0.05+0.10mm Pb	44
C	0.05+0.10mm Pb	45
D10	0.05+0.10mm Pb	44.1
700	F2	44
600	F2	44
620	F2	40
RCF (M3)	FM	39.7
RCF (A)	FM	39.7
IC	IC II	38.8
700	F1	38
RCF (M6)	FM	37.6
600	F1	37
IC	FM	36.8
620	F1	36

Table 4. Comparison of relative reduction in kilovoltage for 10mm Fe at 100 mAmin

Film/paper	Screen	%kV
SR	0.05+0.10mm Pb	100
D2	0.05+0.10mm Pb	98
DR	0.05+0.10mm Pb	88
M	0.05+0.10mm Pb	77
D4	0.05+0.10mm Pb	71
D5	0.05+0.10mm Pb	66
A	0.05+0.10mm Pb	63
D7	0.05+0.10mm Pb	61
C	0.05+0.10mm Pb	61
700	F2	59
600	F2	59
D	0.05+0.10mm Pb	56
D10	0.05+0.10mm Pb	55
620	F2	54
RCF (A)	FM	53
RCF (M3)	FM	52
700	F1	52
600	F1	52
IC	IC II	52
RCF (M6)	FM	52
IC	FM	51
620	F1	50

On analysing the results presented in tables 1 and 2 one can see that the relative speed for X-ray films exposed with lead intensifying screens is almost the same for Al and Fe, though they were exposed at different kilovoltages through different filters. Although the 170- kV X-rays, filtered through 0.05 mm Pb (front intensifying screen) and 30 mm Al lose more intensity than the 215-kV X-rays filtered through 0.05 mm Pb and 10 mm Fe, but this loss is compensated for by the higher sensitivity of the X-ray film to softer X-rays.

For the RCF film with fluorometallic screens the relative speed is higher for 215-kV X-rays filtered through 10 mm Fe than for 170 kV and 30 mm Al. This can, perhaps, be explained by the relatively higher intensification factor of the fluorometallic screens than lead screens.

For radiographic paper exposed with fluoroscent intensifying screens the relative speed is much higher for 170 kV and 30 mm Al than for 215 kV and 10 mm Fe (with the exception of the IC paper exposed with fluorometallic screen). This is, no doubt, caused by the decrease of the intensification of the fluoroscent screens with increasing radiation energy (as shown, e.g. in [11]).

Performing a similar analysis for tables 3 and 4 one can reach to the following conclusions about the relative reduction in kilovoltages: For X-ray films exposed with lead intensifying screens relatively higher kilovoltage is required for films with increasing speed. This is also true for the RCF film and radiographic paper. This means that although the attenuation of 170 kV X-rays in 30 mm Al will be higher than those of 215 kV and 10 mm Fe, the higher sensitivity of X-ray films and papers for lower energy radiation will compensate for that effect.

To be able to formulate more precisely the conclusions about the relative sensitivities of different radiographic systems in relation to such factors as radiation energy, attenuation

in different materials and intensification factors of different intensifying screens a more extensive investigation is needed, based not only on theoretical considerations but also on actual measurements.

14. CONCLUSIONS

- 1) With all fast radiographic systems, analysed in the present investigation, a wire sensitivity better than 2% can be achieved if the kilovoltage is chosen properly.
- 2) The advantages of the fast radiographic systems can be best proved for soft X-rays and light materials (e.g. Al).
- 3) A very considerable reduction of exposure and kilovoltage can be obtained when using films with fluorometallic screens or papers with fluorescent or fluorometallic screens. Other advantages of fast radiographic systems (as enumerated in 4 above) are also of great practical importance.
- 4) The constant exposure technique was shown to be very useful in assessing the advantages of the use of fast radiographic systems. It gave similar results to those obtained by more conventional methods (presented, e.g. in [3]) .

REFERENCES

- 11| J. C. Domanus, P. A. Ruault. Industrial application of radiographic paper. Materialprüfung. 22(1980) Nr.3. pp.111-117.
- 12| J. C. Domanus. Constant exposure technique in industrial radiography. Risø-M-2398. August 1983.
- 13| J. C. Domanus. Fast radiographic systems. Paper to be presented at the 3rd European Conference on Nondestructive Testing. Firenze. 15-18.10.1984.
- 14| J. C. Domanus. Industrial radiography on radiographic paper. Risø Report No. 371. November 1977.
- 15| J. C. Domanus. Application of fluorometallic screens for paper radiography. Risø-M-2395. July 1983.
- 16| J. C. Domanus, C. Mikkelsen. Comparison of X-ray film and paper radiography. Risø-M-1995. April 1978.
- 17| J. C. Domanus, C. Mikkelsen. Comparison of X-ray film and paper radiography. Proceeding of the first European Conference on Non-Destructive Testing. Mainz. 24-26.4.1978, pp. 593-601.
- 18| J. C. Domanus, H. N. Fouly. ISO wire IQI's vs. ASTM penetrameters in paper radiography. Proceedings of the second European Conference on Non-Destructive Testing. Vienna. 14-16.9.1981. Paper B-6.
- 19| J. C. Domanus, H. M. Fouly. Quality of the radiographic image in paper radiography. Risø-M-2314. September 1981.

2440

Risø - M -

<p>Title and author(s)</p> <p>ASSESSMENT OF FAST RADIOGRAPHIC SYSTEMS BY THE CONSTANT EXPOSURE TECHNIQUE by J. C. DOMANUS ATLAS ADVANCED ENGINEERING DIVISION)^x</p>	<p>Date August 1984</p> <p>Department or group</p> <p>METALLURGY</p> <p>Group's own registration number(s)</p>
<p>54 pages + 4 tables + 32 illustrations</p>	
<p>Abstract</p> <p>The constant exposure technique was applied to compare the radiographic image quality and relative speed of different fast radiographic systems. Conventional industrial X-ray films, exposed with lead intensifying screens, special fast film with fluorometallic screens as well as different brands of radiographic paper exposed both with fluorescent as well as fluorometallic screens were tested and compared. ISO wire IQI's and ASTM penetrameters were used together with 30-mm aluminium and 10-mm steel plates. For all the fast radiographic systems wire sensitivity better than 2% was obtained.</p> <p>The constant exposure technique proved to be adequate for the assessment of fast radiographic systems.</p> <hr/> <p>x) Work performed under contract with Risø National Laboratory</p> <p>Available on request from Risø Library, Risø National Laboratory (Risø Bibliotek), Forsøgsanlæg Risø), DK-4000 Roskilde, Denmark Telephone: (03) 37 12 12, ext. 2262. Telex: 43116</p>	<p>Copies to</p>