



SOFC anode reduction studied by in situ TEM

Simonsen, Søren Bredmose; Wagner, Jakob Birkedal; Hansen, Thomas Willum; Agersted, Karsten; Hansen, Karin Vels; Jacobsen, T.; Kuhn, Luise Theil

Publication date:
2013

Document Version
Publisher's PDF, also known as Version of record

[Link back to DTU Orbit](#)

Citation (APA):
Simonsen, S. B., Wagner, J. B., Hansen, T. W., Agersted, K., Hansen, K. V., Jacobsen, T., & Kuhn, L. T. (2013). *SOFC anode reduction studied by in situ TEM*. Abstract from Scandem 2013 - Annual Meeting of the Nordic Microscopy Society, Copenhagen, Denmark.

General rights

Copyright and moral rights for the publications made accessible in the public portal are retained by the authors and/or other copyright owners and it is a condition of accessing publications that users recognise and abide by the legal requirements associated with these rights.

- Users may download and print one copy of any publication from the public portal for the purpose of private study or research.
- You may not further distribute the material or use it for any profit-making activity or commercial gain
- You may freely distribute the URL identifying the publication in the public portal

If you believe that this document breaches copyright please contact us providing details, and we will remove access to the work immediately and investigate your claim.

SOFC anode reduction studied by in situ TEM

S.B. Simonsen^{1*}, J.B. Wagner², T.W. Hansen², K. Agersted¹, K.V. Hansen¹, T. Jacobsen¹, L.T. Kuhn¹

¹DTU Energy Conversion, Frederiksborgvej 399, DK-4000 Roskilde, Denmark

²CEN, Technical University of Denmark, DK-2800 Kgs. Lyngby, Denmark

*sobrs @dtu.dk

The Solid Oxide Fuel Cell (SOFC) is a promising part of future energy approaches due to a relatively high energy conversion efficiency and low environmental pollution. SOFCs are typically composed of ceramic materials which are highly complex at the nanoscale. TEM is routinely applied ex situ for studying these nanoscale structures, but only few SOFC studies have applied in situ TEM to observe the ceramic nanostructures in a reactive gas environment at elevated temperatures.

The present contribution focuses on the reduction of an SOFC anode which is a necessary process to form the catalytically active Ni surface before operating the fuel cells. The reduction process was followed in the TEM while exposing a NiO/YSZ (YSZ = Y₂O₃-stabilized ZrO₂) model anode to H₂ at T = 250-1000°C. Pure NiO was used in reference experiments. Previous studies have shown that the reduction of pure NiO is a relatively rapid autocatalytic process. On the contrary, the reduction of NiO/YSZ is significantly slower, which indicates that the presence of YSZ inhibits the reduction of NiO. This study aims to obtain fundamental insight into this reduction mechanism and to explain the inhibitive influence of YSZ.

A Titan E-Cell 80-300ST TEM was used for the in situ work in combination with the chip-based Aduro heating holder from Protochips. Since the chip-based heating holder does not allow internal temperature measurements, and since the temperature of the chips are only calibrated in vacuum, part of the presentation will focus on temperature calibration.