



## Thermodynamics of Phase Change Solvents

Waseem Arshad, Muhammad; Thomsen, Kaj; von Solms, Nicolas; Svendsen, Hallvard Fjørne

*Publication date:*  
2013

*Document Version*  
Publisher's PDF, also known as Version of record

[Link back to DTU Orbit](#)

*Citation (APA):*  
Waseem Arshad, M. (Author), Thomsen, K. (Author), von Solms, N. (Author), & Svendsen, H. F. (Author). (2013). Thermodynamics of Phase Change Solvents. Sound/Visual production (digital)

---

### General rights

Copyright and moral rights for the publications made accessible in the public portal are retained by the authors and/or other copyright owners and it is a condition of accessing publications that users recognise and abide by the legal requirements associated with these rights.

- Users may download and print one copy of any publication from the public portal for the purpose of private study or research.
- You may not further distribute the material or use it for any profit-making activity or commercial gain
- You may freely distribute the URL identifying the publication in the public portal

If you believe that this document breaches copyright please contact us providing details, and we will remove access to the work immediately and investigate your claim.

# Thermodynamics of Phase Change Solvents

**Muhammad Waseem Arshad**

**Supervisors: Assoc. Prof. Kaj Thomsen (DTU)**

**Assoc. Prof. Nicolas von Solms (DTU)**

**Prof. Hallvard Fjøsne Svendsen (NTNU)**


# Outline

- Introduction
- Experimental Work
  - Freezing Point Depression
  - Heat of Absorption
  - Vapor liquid equilibrium
- Thermodynamic Modeling
  - DEEA-CO<sub>2</sub>-H<sub>2</sub>O
- Main Conclusions
- Future work

# Introduction

## 2-(diethylamino)ethanol (DEEA)

- Low heat of reaction (bicarbonate)
- Low heat requirement for reversion
- High loading capacity
- Low reaction rate



## 3-(methylamino)propylamine (MAPA)

- Fast reaction rate
- High heat of reaction (carbamate)
- High heat requirement for reversion




# Introduction


DEEA-MAPA-CO<sub>2</sub>-H<sub>2</sub>O system give liquid-liquid split with lower phase rich in CO<sub>2</sub> and upper phase lean in CO<sub>2</sub>

- Phase change solvents has potetial for:
  - Low ciculation rate in the desorber
  - Smaller size of desorber (low capital cost)
  - Improved energy efficiency

Phase change solvent



# Introduction




## Freezing Point Depression

- Measurement of freezing point is considered the most accurate method to determine water activity
  - Water activity is a key parameter for the amount of water evaporated in the desorber
  - Low water activity means less evaporation of water in the desorber and low energy consumption during solvent regeneration
  - Water activity is only a weak function of temperature
  - Water activity measured at low temperature is not very different from water activity at absorber and stripper temperatures
  - Water activity is very useful for thermodynamic modelling

# Experimental: Freezing Point Depression



- A, Thermostatic bath with ethanol
- B, Cooling jacket
- C, Sample glass with magnetic stirrer
- D, Rubber stopper with sample glass lid
- E, Device for manual stirring
- F, Controlled temperature ethanol bath with magnetic stirrer
- G, Pt100 Thermometer
- H, Data acquisition unit



Fosbøl, P. L.; Pedersen, M. G.; Thomsen, K. J. *Chem. Eng. Data* **2011**, 56, 995-1000.





# Experimental: Freezing Point Depression



Fosbøl, P. L.; Pedersen, M. G.; Thomsen, K. J. *Chem. Eng. Data* **2011**, 56, 995-1000.


# Results: Freezing Point Depression

DEEA-H<sub>2</sub>O and MAPA-H<sub>2</sub>O

DEEA-MAPA-H<sub>2</sub>O



Arshad, M. W.; Fosbøl, P. L.; von Solms, N.; Thomsen, K. J. *Chem. Eng. Data* **2013**, published online.

# Results: Freezing Point Depression


## DEEA-CO<sub>2</sub>-H<sub>2</sub>O




## MAPA-CO<sub>2</sub>-H<sub>2</sub>O



# Experimental: Heat of Absorption and VLE of CO<sub>2</sub>



# Experimental: Heat of Absorption and VLE of CO<sub>2</sub>



## Tested Concentrations


- 5M DEEA
- 2M MAPA
- 1M MAPA
- 5M DEEA + 2M MAPA (phase split)
- 5M DEEA + 1M MAPA (phase split)

Temperature = 40 °C (absorption), 80 °C and 120 °C (desorption)

Total Pressure = ~6 bar

# Sample Results: Heat of Absorption

## Overall comparison of all systems at Absorption & Desorption conditions




# Sample Results: Vapor-Liquid Equilibrium of CO<sub>2</sub>

## VLE of CO<sub>2</sub> in 5M DEEA

Blue Data from Calorimeter - This work

Red Data from Equilibrium Cell – iCap D1.3.2





# Thermodynamic Modeling

- Amine-CO<sub>2</sub>-H<sub>2</sub>O systems are electrolyte systems
- Extended UNIQUAC, an electrolyte thermodynamic model will be used to model the phase change solvents system
- The systems to be modeled are:
  - DEEA-CO<sub>2</sub>-H<sub>2</sub>O
  - MAPA-CO<sub>2</sub>-H<sub>2</sub>O
  - DEEA-MAPA-CO<sub>2</sub>-H<sub>2</sub>O (phase split)

# Extended UNIQUAC

- Extended UNIQUAC = Original UNIQUAC + Extended Debye-Hückle

$$\frac{G^E}{RT} = \underbrace{\left( \frac{G^E}{RT} \right)_{\text{Combinatorial}} + \left( \frac{G^E}{RT} \right)_{\text{Residual}}}_{\text{UNIQUAC entropic term}} + \left( \frac{G^E}{RT} \right)_{\text{Extended Debye-Hückle}}$$

UNIQUAC entropic term  
 $r$  = volume parameter  
 $q$  = surface area parameter



UNIQUAC enthalpic term  
 Binary interaction energy parameter  
 $u_{ij} = u_{ij}^0 + u_{ij}^T (T - 298.15)$

Electrostatic interaction




- Liquid phase activity coefficients are calculated with the UNIQUAC equation
- Vapor phase fugacity coefficients are calculated with SRK EoS

# Modeling: DEEA-CO<sub>2</sub>-H<sub>2</sub>O


## Physical equilibria:




## Chemical equilibria:




# Vapor Pressure of DEEA




# Freezing Point Depression of DEEA




# Excess Molar Enthalpy of DEEA



# VLE of CO<sub>2</sub> in 5M DEEA



# Heat of Absorption of CO<sub>2</sub> in 5M DEEA





## Main Conclusions

- Freezing point depressions were measured in CO<sub>2</sub> loaded and unloaded systems
  - Unloaded systems: DEEA-H<sub>2</sub>O, MAPA-H<sub>2</sub>O and DEEA-MAPA-H<sub>2</sub>O
  - Loaded systems: DEEA-CO<sub>2</sub>-H<sub>2</sub>O and MAPA-CO<sub>2</sub>-H<sub>2</sub>O
- Heat of absorption and VLE of CO<sub>2</sub> data were measured at 40, 80 and 120°C for the systems:
  - 5M DEEA and 2M & 1M MAPA
  - 5M DEEA + 2M MAPA (phase split)
  - 5M DEEA + 1M MAPA (phase split)
- Model parameters were determined for the DEEA-CO<sub>2</sub>-H<sub>2</sub>O system

# Future Work

- Improving the model parameters for DEEA-CO<sub>2</sub>-H<sub>2</sub>O system
- Modeling the MAPA-CO<sub>2</sub>-H<sub>2</sub>O and DEEA-MAPA-CO<sub>2</sub>-H<sub>2</sub>O systems

# Acknowledgement

- This project is fully funded by European Commission under the 7th Framework Program (Grant no. 241393) through iCap project



# Thank You!